

# WATERWORKS

## INSTALLATION GUIDELINES

STYLE No. MOMR01 & MOMR02

Montgomery Metal Rectangular Wall Mounted Stationary Mirror

### IMPORTANT:

- ◇ To ensure this product is installed properly, you must read and follow these guidelines.
- ◇ The owner/user of this product must keep this information for further reference.
- ◇ This product must be installed by a professional licensed contractor.
- ◇ Inspect this product to ensure you have all the parts required for proper installation.

### CONTENTS:

- (1) MIRROR
- (4) POSTS
- (4) POST NUTS
- (4) CAP SCREWS
- (8) "O" RINGS
- (4) #8 x 1 ¼" SCREWS
- (4) ANCHORS

### INSTALLATION:

- ◇ **Products may vary, find mounting points from enclosed mirror.**
  - ◇ **Anchors & screws provided are for drywall or similar walls. Use anchors & screws appropriate for your installation.**
1. Using MIRROR mark ANCHOR locations
  2. Install ANCHORS at marked location.
  3. Place SCREW through POST and screw each into ANCHORS until tight.
  4. Place "O" RING over threaded portion of each POST.
  5. Hang MIRROR on POSTS and hold during steps 6 & 7.
  6. Place "O" RING over threaded portion of each POST.
  7. Screw each POST NUT onto POST until hand tight. **DO NOT OVERTIGHTEN.**
  8. Screw CAP SCREW into POST until flush with surface.

