

## 2 PANEL SLIDING DOOR WITH SIDE PANEL

**INSTALLATION GUIDE** 

## IMPORTANT: Please read the complete instructions before commencing fitting.

Make sure the tray is 100% level in all directions.

Check that you have the tools required. □

Check the installation site is compatible with the sizes of door supplied.  $\Box$ 


Check all the enclosure components are present. □


Check the installation kit is complete. □

Do Not attempt to install the product unless you can tick all 4 boxes.


The wall plugs supplied with the installation kit are for use in solid walls. Hollow or 'stud partition' walls will require alternative fixings. Please consult a hardware supplier for the correct type. It may also be necessary to consult your tiling supplier about the correct method for drilling your tiles.

ATTENTION: TAKE EXTREME CARE WHEN HANDLING GLASS, WEAR PROTECTIVE EYEWEAR AND CLOTHING. DO NOT LEAVE THE GLASS ON HARD SURFACES AND AVOID CONTACT BETWEEN THE GLASS EDGES AND HARD SURFACES OR IMPACTS DURING THE INSTALLATION.







2.





No.	QTY	descriptions	Code	No.	QTY	descriptions	Code	No.	QTY	descriptions	Code
1	2	Wall profile	SP0GMS0680	11)	1	Middle bracket	SP0GMS0739	21)	2	Roller	SP0GMS0710
2	2	Bracket fixing screws M4x10	SP0GMS0719	12	2	M5x10 screw	SP0GMS0745	22	1	Moving panel upright seal	SP0GMS0699
3	1	Fixed panel wall bracket	SP0GMS0711	13	3	M5x12 screw	SP0GMS0846	23	1	fixed panel upright seal	SP0GMS0698
4	1	Plastic grub screw	SP0GMS0717	14	2	M5x14 screw	SP0GMS0738	24)	1	side panel closing seal	SP0GMS0702
5	2	M6x6 grub screw	SP0GMS0718	15	1	corner bracket	SP0GMS0732	25)	1	Threshold	С
6	4	Wall plug	SP0GMS0849	16	2	M4x12 screw	SP0GMS0769	26	1	Threshold corner bracket	SP0GMS0773
7	2	5x40 screw	SP0GMS0847	17	1	Side panel clamp	SP0GMS0768	27)	1	Fixed panel	D
8	1	Top rail	Α	18	1	side panel wall bracket	SP0GMS0762	28	1	Moving panel	E
9	2	Roller stop	В	19	1	side panel wall bracket cover cap	SP0GMS0770	29	1	Handle	F
10	4	Roller stop screws	SP0GMS0709	20	2	M5x40 Pan head screw	SP0GMS0848	(30)	1	Side panel	G





3.
















**7A** 1. On the glass fixing bracket remove the protective film from the tape and keep end with X to the top.


Then fit the fixing bracket to the outside of the glass.


**7B** Slide the bracket down over the glass fixing.


7C Loosely fix the the glass clamp to the wall bracket with Pan head screws to allow adjustment.












































## **MERLYN**

Merlyn Showering Unit 8, Purcellsinch Industrial Park, Dublin Road, Kilkenny, Ireland. Tel: 00353 56 779 1555

Fax: 00353 56 779 1576

www.merlynshowering.com

To download the Declaration of Performance (DOP) for this product please use the link below. <a href="https://merlynshowering.com/aftersales-support/dop-certs/">https://merlynshowering.com/aftersales-support/dop-certs/</a>