





ASSEMBLY INSTRUCTION / ИНСТРУКЦИЯ

A1810PL-1BK
A1810PL-1WH
A1811PL-1BK
A1811PL-1WH

A1820PL-1BK
A1820PL-1WH
A1821PL-1BK
A1821PL-1WH

A1830PL-1BK
A1830PL-1WH
A1831PL-1BK
A1831PL-1WH



Warning:

1. Turn off the main power at the circuit breaker before installing in order to prevent possible shock;
2. Don't exceed the rated voltage 230V;
3. Don't install on haven't finished ceiling and loose wood ceiling;
4. Do not use corrosive liquids to clean fixture such as acid, and alkaline liquids. Please use soft cloth when cleaning.