

RUGS & BASKETS CARE & MAINTENANCE



Material Properties

Gloster rugs and baskets are made from a flat braid of Sunbrella 100% solution dyed acrylic fibres. This braid is then hand-guided as it is hand-sewn together to create the finished product. One of the best ways to keep outdoor rugs and baskets looking good and to delay the need for wet cleaning is to remove any dirt before it can become embedded within the structure of the braid by either vacuuming or hosing down with clean water on a regular basis. We recommend that any spills are wiped up as soon as possible and spot cleaning take place straight away should any stains occur.

Spot Cleaning

1. Absorb as much of the stain as possible with a clean, dry cloth.
2. Prepare a cleaning solution of 1:16 mild detergent to lukewarm water (less than 100°F/40°C).
3. Apply a light mist of the cleaning solution to the stain using a spray bottle.
4. Work the cleaning solution into the stain by lightly agitating with a sponge.
5. Rinse thoroughly with clean water to remove all soap residue.
6. Blot excess moisture with a clean, soft towel or sponge.
7. Repeat steps 2 to 6 until the stain is removed.
8. Lay the rug/basket flat and allow to air dry.

Wet Cleaning

1. Vacuum off any loose dirt.
2. Prepare a cleaning solution of 1:16 mild detergent to lukewarm water (less than 100°F/40°C).
3. Work the cleaning solution in by lightly agitating using a sponge.
4. Allow the cleaning solution to soak in.
5. Rinse thoroughly to remove all soap residue.
6. Lay the rug/basket flat and allow to air dry.

General Tips

Do not dry clean. Do not use bleach or aggressive detergents. Do not use a vacuum cleaner with a rotating brush (beater bar).

Store outdoor rugs and baskets in a dry location when not in use.

Rugs are fully reversible.