

Article 495



Materia prima: Ottone Funzionamento: Acqua calda

Si è elaborato il seguente manuale d'uso allo scopo di fornire le informazioni appropriate per l'installazione e le precauzioni da adottare da parte dell'installatore e dell'utilizzatore. **Il costruttore declina ogni responsabilità in caso di utilizzo dell'apparecchio al di fuori delle istruzioni fornite.**

ATTENZIONE: Questo apparecchio può essere utilizzato solo per supporto di asciugamani o simili. L'apparecchio nel suo normale utilizzo non deve essere caricato con un peso superiore a **5Kg**

Utilizzare solo le viti e i tasselli in dotazione o sostituirli con altre di uguali o maggiori caratteristiche di tenuta meccanica

GRADO DI PROTEZIONE: Apparecchio protetto contro gli spruzzi. (IPX4)

CONTENUTO DELLA CONFEZIONE :
(vedi immagine 1)

- (2) Rosoni
- (2) Aste per attacco a muro
- (2) Guarnizioni
- (2) Perni di fissaggio
- (1) Confezione di viti e tasselli
- (2) Eccentrici
- (2) Blocchetti a muro di connessione

INSTALLAZIONE:

1. Rimuovere lo scaldasalviette e i suoi componenti dall'imballo
2. Fare predisporre dall'installatore due attacchi a muro verticali F. da 1/2" con interasse di 575mm
3. Applicare i rosoni sulle calotte.
4. Eseguire 2 fori con una punta Ø 8 nel muro in corrispondenza della posizione del supporto delle aste. (int.153mm)
5. Avvitare lo scaldasalviette sui tubi che escono dal muro (se serve utilizzare gli eccentrici), serrando in modo idoneo gli appositi dadi (muniti di guarnizione) con una chiave da 29mm e fissare lo scaldasalviette al muro avvitando i perni agli appositi supporti.
6. A questo punto l'articolo è pronto e può essere messo in funzione.

Raw material : Brass Operation: Hot water

The following manual has been elaborated in order to supply all the useful information for a correct installation together with the precautions to adopt both from installer and users. **Manufacturer declines every responsibility in case of different uses from these instructions.**

ATTENTION :This item can be only used as holder for towels and similar garments.
This item, in normal use, cannot be loaded with more than **5 Kg.** weight.

Please, only use provided screws and dowels or replace them with other equivalent ones or others greater in mechanical characteristics.

PROTECTION DEGREE: Spatters resistant. (IPX4)

PACKAGE CONTENTS :
(see image 1)

- (2) Washers
- (2) Wall holder bars
- (2) Green gaskets
- (2) Fixing bolts
- (1) Screws and dowels confection
- (2) Eccentric nipples
- (2) Wall connecting nuts

INSTALLATION:

1. Take out the heated towel rail and its components from the package.
2. Let the plumber predispose two vertical F 1/2 " connections out coming from the wall with 575mm distance between hole centres.
3. Apply the provided washers beneath the wall nuts.
4. With a Ø 8 drill make 2 holes in correspondence of the bar holders position. (int.153mm)
5. Screw the towel warmer up to the threaded pipes coming out from the wall (use the eccentric nipples if needed), then tight the provided nuts up (with their fitted gaskets) with help of a 29mm key and fix the towel warmer to the wall by screwing the proper bolts.
6. At this point the item is ready to work.

1)

