

Dornbracht

Sensory Sky

Just like being in the open air. SENSORY SKY turns showering into a unique experience that awakens all your senses. Different types of rain, mist, light and fragrances complement each other in complex choreographies which are inspired by weather phenomena and the moods of nature.

Choreographies

① reAdjust

READJUST sharpens the senses. Mist and warm rain reduce the daily flood of stimuli to a pleasant minimum – until the sky gradually clears and perception is more focussed and intensified: where is this pleasantly soft dry forest floor fragrance coming from?


② reRelease

RELEASE is an intensive summer rain which is both cleansing and liberating. Accumulated energies erupt in an expressive choreography composed of different types of rain and different temperatures – accompanied by a refreshing, tropical-like fragrance.

③ reJoyce

REJOICE protects, envelops and stabilises. The external rain curtain is a projection screen for the light with water drops sparkling in all the colours of the rainbow – a multifaceted, harmonious interplay of colours and fragrances which is gradually transferred to the whole body.

Logic controls



Functions

- Activated by pressing or turning any control element.
- Waiting display: if a function has been selected but is not yet ready, the appropriate symbol will flash. It will stop flashing as soon as the function is ready for use.
- Deactivation of individual active functions by pressing the appropriate button.
- Deactivation of all active functions by pressing the rotary knob for temperature or volume.
- Individual configuration: if several outlet points are active at the same time, the temperature and volume of a desired outlet point can be adjusted individually by pressing and holding the appropriate button. Pressing both rotary knobs at the same time will reset the temperature and volume to their default values.
- Pause function: individual settings are saved for five minutes after the water has been switched off.