



VOLA A62, A63, A63F
VOLA VR1795


Fitting instruction
Montageanleitung
Monteringsvejledning
Monteringsvægledning
Montage hanleiding
Manuel de montage




A62



A63, A63F




A63F




VR1795




VR1795 & A63:




VR1795 & A62:



A62:



A63:




www.vola.com

A62 V2_40999693



vola



1

Plumbers putty
Installationskit
Sanitetskit



Sanitetskit
loodgieters mastiek
Mastic sanitaire



2


Operating
Bedienung
Betjening
Not/Nicht/Ikke/Inte/Niet/Pas: A63F

Bruk
Bedienung
Fonctionnement




3







1795 + A63 ~~1795 + A62~~



Distance collar. Not included in the delivery.
 Distanzring. Nicht im Lieferumfang enthalten.
 Afstandsring. Indgår ikke i leverancen.
 Avståndsring. Ingår inte i leveransen.
 Afstandsring. Niet inbegrepen in de levering
 Anneau de distance. Non inclus dans la livraison.



vola
 Lunavej 2
 DK-8700 Horsens
 Tlf : + 45 7023 5500
 sales@vola.com
 www.vola.com

VOLA A62, A63, A63F

| | |
|-------|---------|
| Date | Sep. 05 |
| Rev. | 3 |
| Sheet | SB 96.1 |