







VOLA HV1, HV3, HV4



Fitting instruction
 Montageanleitung
 Monteringsvejledning
 Monteringsvægledning
 Montage hanleiding
 Manuel de montage

 **GODKENDT
 TIL DRILLEKVVAND**
 HV1, HV3:
 04/00020
 04/00028




HV1, HV3	L	H	h
Std.:	114 mm 4 1/2"	120 mm 4 3/4"	27 mm 1"
+30:	114 mm 4 1/2"	150 mm 6"	56 mm 2 1/4"
/150:	150 mm 6"	120 mm 4 3/4"	27 mm 1"
+30/150:	150 mm 6"	150 mm 6"	56 mm 2 1/4"
+170:	114 mm 4 1/2"	290 mm 11 1/2"	197 mm 7 3/4"
+170/150:	150 mm 6"	290 mm 11 1/2"	197 mm 7 3/4"





5

HV1L/HV1M
HV3L/HV3M
HV4L/HV4M



5



Data, 3 Bar/43.5 Psi:

Max.	l/min.	Gal/min.	Note.
HV1/3:	5.0	1.3	Standard
HV1/3:	4.5	1.2	Standard USA
HV1/3:	9.0	1.8	Standard Japan
HV4	9,0	1.8	

Max. 70°C, 158°F




HV1




HV3




HV4





- | | |
|------------|--|
| VR277K: | VR22, VR269, VR277 |
| *VR17L4K: | VR15P, VR16L4, VR17L (US-Standard) |
| *VR17L5K: | VR15P, VR16L5, VR17L (Standard) |
| *VR17L9K: | VR15P, VR16L9, VR17L (Japan Standard) |
| *VR17LSK: | VR15P, VR16LS, VR17L |
| VR297/L/M: | VR20, VR22, VR269, VR273/L/M, VR277, VR294, VR295, VR296 |
| VR433: | VR261, VR263, VR440, VR442, 2xVR444 |
| NR.10/L/M: | VR20, VR22, VR273/L/M, VR294, VR295 |



vola
 Lunavej 2
 DK-8700 Horsens
 Tlf : + 45 7023 5500
 sales@vola.com
 www.vola.com

VOLA HV1

Date
Okt. 16

Rev.
6

Sheet
SB 21.1