
















Instrucciones de montaje
Assembly instructions


Serie HELSINKI








Salsar







1  x3 ST4X40	2  x3	3  x1	5  x1	31  x1	32  x2	33  x1	34  x2 M5X20	35  x1	36  x1
37  x1									















	B(mm)
675	670.5~690.5
775	770.5~790.5
875	870.5~890.5



3



4



c



5

