


cersanit



RU инструкция по монтажу и эксплуатации настенных смесителей

PL instrukcja montażu i obsługi baterii ściennych

EN installation and operation manual for wall-mounted faucets

KK qabyrgalyq aralastyrgysharga arналған montajday және ekspliyatsiia бойynsha nusqaylyq

AZ divardan asılan su kranlarının quraşdırılması və istismar üzrə təlimat

UZ devorga ilinadigan smesitellarni o'rnatish va foydalanish bo'yicha yo'riqnomasi

KG lyubalga asma chabyshyrgychy ornottu jana ish tetgu boюнча nuskaма







KA ვედლის შემრევის მონტაჟის და ექსპლუატაციის ინსტრუქცია

TK divar garyjlyary gurnamak we ulanmak boynuça gözükdirme

HY Պատե ծորակների տեղադրման և շահագործման հրահանգ

TJ дастурамал оид ба насбкунӣ ва истифодабарии омехтакунандаҳи деворӣ

MN ханын ус холигч угсрах ба ашиглах заавар



CERSANIT THERMO-BLOCK

