



ASSEMBLY INSTRUCTION



ИНСТРУКЦИЯ

A1528LM-5WH, A1528LM-8WH

01

02

03

04

05

06

07

08

09

10

11

OFF

ON

14

6 mm

L N L N