


NENE & NENA

*Timeless jewelry for your home*

nomon

# How to change the battery?

Cómo cambiar la pila?




Insert the key into the hole and  
press the front case forward.

Insertar la llave por el agujero y  
presionar la caja delantera.

Attention!  
Atención!  
R6 1,5V

## How to set the clock?

*Cómo poner el reloj en hora?*



Turn the minute hand clockwise until both hands are 12 o'clock. Continue turning until the desired time is reached.

Girar cuidadosamente la aguja minutos hasta alcanzar las 12:00, continuar girando hasta la hora deseada.

NEVER turn the hands in anti-clockwise direction.

NUNCA girar las agujas en sentido antihorario.



*Handmade clocks in Barcelona*

[www.nomon.es](http://www.nomon.es)