



WWGB18 (18" length)**WWGB24** (24" length)**WWGB36** (36" length)**Notes:**

- Blocking in the wall to adequately secure grab bar is mandatory.
- Mounting hardware is included.
- ADA compliant.

ROUGH IN:

➤ **REQUIRED:** Blocking in the wall to adequately secure the grab bar is mandatory.

1. Based on user preferences, locate the proper position of the grab bar.
2. Install blocking of the appropriate material and dimension to mount the grab bar. If using wood stud construction, a 2x6 or 2x8 on its side provides a range of positioning options. Do NOT rely on the thickness of the tile or other wall material alone to adequately secure the grab bar.

INSTALLATION:

3. Pull back on the snap-on flange covers from both ends of the bar so the 3 mounting holes on each flange are accessible.
 4. Place the grab bar in the proper position and, while using the grab bar as a template, mark the location of the holes to be used for mounting the grab bar to the wall.
 5. Secure the grab bar using the 6 - 2" stainless screws provided. If using metal stud construction, or the wall material is too thick, do not use the screws provided and instead, find an appropriate stainless steel screw.
 6. Slide the flange covers over each o-ring so it contacts the surface of the finished wall. If desired, a bead of silicone can be applied between the flange cover and surface of the finished wall.
- If further assistance is required, please contact Product Support at 1-800-927-2120 (8am-7pm EST).

INSTALLATION GUIDELINES:**IMPORTANT:**

- To ensure this product is installed properly, you must read and follow these guidelines.
- The owner/user of this product must keep this information for future reference.
- Blocking in the wall to adequately secure the grab bar is mandatory. Failure to adequately secure the grab bar may result in serious injury.
- Inspect this product to assure you have all parts required for proper installation.
- Be sure your installation conforms to all applicable codes.
- This product must be installed by a professional contractor.
- Refer to the specification and assembly drawings attached.