



Dornbracht

Horizontal Shower^{ATT}

Checklists – installation supervision

02 Introduction

03 Planning advice

09 Concealed rough parts

12 Exposed trim parts / commissioning

INTRODUCTION

Planning advice

Concealed rough parts

Exposed trim parts / commissioning

Introduction

It is obligatory for technical planning, installation and initial commissioning to be accompanied by a certified service partner and by booking a Dornbracht service package. Detailed information on the service package can be found at www.dornbracht-professional.com.

Planning advice

.....
Order number (SO)

.....
Project / end customer

.....
Address

.....
Phone

.....
E-mail

.....
Additional contact

.....
Phone

.....
E-mail

.....
Person responsible for planning

.....
Address

.....
Phone

.....
E-mail

.....
Fitter

.....
Address

.....
Phone

.....
E-mail

.....
Electrician

.....
Address

.....
Phone

.....
E-mail

.....
Service partner / Dornbracht

.....
Address

.....
Phone

.....
E-mail

Plumbing installation 1

Planning for the HORIZONTAL SHOWER^{ATT} can be checked for completeness more easily with this checklist.

Operating conditions

Measuring point: Concealed rough parts for eVALVE

<input type="checkbox"/> Cold water temperature		5 – 20 °C /	41 – 68 °F
<input type="checkbox"/> Recommended cold water temperature		15 °C /	59 °F
<input type="checkbox"/> Hot water temperature		55 – 65 °C /	131 – 149 °F
<input type="checkbox"/> Recommended hot water temperature		60 °C /	140 °F
<input type="checkbox"/> Thermal disinfection (max. 10:00 mins.)		< 75 °C /	< 167 °F
<input type="checkbox"/> Permissible flow pressure	250 – 400 kPa /	36 – 58 psi /	2.5 – 4 bar
<input type="checkbox"/> Recommended flow pressure	300 kPa /	44 psi /	3 bar
<input type="checkbox"/> Maximum difference in flow pressure between HW + CW	100 kPa /	14,5 psi /	1 bar
<input type="checkbox"/> Recommended difference in flow pressure between HW + CW	≤ 50 kPa /	≤ 7 psi /	≤ 0,5 bar
<input type="checkbox"/> Recommended water hardness	6 – 7 °dH / 107 – 125 ppm /	7.5 – 8.8 °e /	10.7 – 12.5 °fH

Special features / comments

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....
 Order number (SO)

.....
 City

.....
 Date

.....
Service partner / Dornbracht

.....
Person responsible for planning

.....
Fitter

.....
Electrician

Plumbing installation 2

Planning for the HORIZONTAL SHOWER^{ATT} can be checked for completeness more easily with this checklist.

Plumbing installation

- Pipework calculation (in accordance with EN 806-3, DIN 1988-300)
- Assessment of demand for the hot water supply on an individual basis (e.g. in accordance with DIN 4708-200, DIN 4753-7, VDI 6003)
- Assessment of demand for the drain on an individual basis (e.g. in accordance with DIN 1986-100, EN 12056-1/-2), AW 2.1 l/s / 0.6 gpm, DN 75
- The following components for the hot and cold water pipe must be positioned so that access is possible at all times (accessible for inspection): 2 x stop valve (DN 20), 2 x dirt trap (DN 20).
- Filter (main pipe)
- Pressure reducing valve (main pipe)
- Water softener (main pipe)
- Speed-controlled pressure booster (e.g. in accordance with DIN 1988-500)
- 900 mm / 2 ft 11-3/8" minimum distance between the circulation pipe connection (C) and the first eVALVE of the HORIZONTAL SHOWER^{ATT}
- 300 mm / 11-3/4" minimum distance (centre / centre) of concealed rough parts for 6 x WATER BAR

Required nominal diameter (DN) for pipes and fittings:

- DN 20 – hot and cold water pipe (HW + CW)
- DN 20 – ring main (loop)
- Testing the rough-in for leaks (in accordance with EN 806-4 / DIN 1988-200)
- Flushing the pipes after rough-in (in accordance with EN 806-4 / DIN 1988-200)

Special features / comments

.....
.....
.....
.....
.....

.....
Order number (SO)

..... City Date Service partner / Dornbracht
..... Person responsible for planning Fitter Electrician

Dry construction

Planning for the HORIZONTAL SHOWER^{ATT} can be checked for completeness more easily with this checklist.

Pre-wall system

Compliance with building services fire protection.

Note the recess depths of the components:

- | | | | |
|--|----------------------|---|-----------------------|
| <input type="checkbox"/> Components (6 x WATER BAR) and mounting frame | min. 153 mm / 6" | – | max. 176 mm / 7" |
| <input type="checkbox"/> Wall with hand shower set, if present | min. 141 mm / 5-1/2" | – | max. 164 mm / 6-1/2" |
| <input type="checkbox"/> Wall with SMART TOOLS control elements: | min. 141 mm / 5-1/2" | | |
| <input type="checkbox"/> Maximum thickness of the panelling for the SMART TOOLS control elements | | | 30 mm / 1-1/8" |
| <input type="checkbox"/> Construction (tiles, natural stone, etc.), for the SMART TOOLS control elements | | | 7 – 25 mm / 1/4" – 1" |

Special features / comments

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....
Order number (SO)

..... City Date Service partner / Dornbracht
..... Person responsible for planning Fitter Electrician

Electrical installation 1

Planning for the HORIZONTAL SHOWER^{ATT} can be checked for completeness more easily with this checklist.

Fuse box with electrical components

- Outside the wet zone
- Accessible for inspection
- 5 – 35 °C / 41 – 95 °F ambient temperature
- Space required for electrical components in the fuse box: min. 500 x 500 x 150 mm / 1 ft 7-3/4" x 1 ft 7-3/4" x 6" (inside)

Provided by customer:

- Safety cut-out (6 A)
- Ground fault circuit interrupter (30 mA, 2-pin, type A)
- 1 x Circuit-breaker switch (16 A)
- 2 x Rail mounting TS 35
- Equipotential bonding rail
- A network socket wired in accordance with TIA 568A, if necessary
- Equipotential bonding at the fuse box and within the fuse box (4 mm² / AWG 11)

Special features / comments

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....
Order number (SO)

.....
City

.....
Date

.....
Service partner / Dornbracht

.....
Person responsible for planning

.....
Fitter

.....
Electrician

Electrical installation 2

Planning for the HORIZONTAL SHOWER^{ATT} can be checked for completeness more easily with this checklist.

Installation

- Electrical installation must be carried out by a professional specialist, in accordance with DIN VDE 0100
- Do not roll up excess cable lengths. Shorten the excess cable lengths or fasten them in a meandering pattern.
- 6 / 7 x equipotential bonding 4 mm² / AWG 11 for 6 x WATER BAR and hand shower set, if applicable
- The VBUS connection of electrical components (daisy chain) must end with a terminator.
- Daisy chain in accordance with the planning information
- The total length of the daisy chain may not exceed 30,000 mm / 98 ft 5-1/8".
- The concealed rough parts for eVALVES and SMART TOOLS, as well as the VBUS cable must be fitted and tested before the pre-wall is closed.
- 90 mm / 3-1/2" minimum horizontal and/or vertical distance (centre / centre) for SMART TOOLS control elements
- The distance must never be less than this!-
- Ø 56 mm / Ø 2-1/4" drilled hole in the panelling for the SMART TOOLS control elements concealed rough parts
- 42±1 mm x 42±1 mm / 1-5/8" x 1-5/8" cutout in the wall construction (tiles, natural stone, etc.)

Special features / comments

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

Order number (SO)

.....
City

.....
Date

.....
Service partner / Dornbracht

.....
Person responsible for planning

.....
Fitter

.....
Electrician

Concealed rough parts

.....
Order number (SO)

.....
Project / end customer

.....
Address

.....
Phone

.....
E-mail

.....
Additional contact

.....
Phone

.....
E-mail

.....
Person responsible for planning

.....
Address

.....
Phone

.....
E-mail

.....
Fitter

.....
Address

.....
Phone

.....
E-mail

.....
Electrician

.....
Address

.....
Phone

.....
E-mail

.....
Service partner / Dornbracht

.....
Address

.....
Phone

.....
E-mail

Dry construction / plumbing

Planning for the HORIZONTAL SHOWER^{ATT} can be checked for completeness more easily with this checklist.

Checks to be made:

- Recess depths (min. / max.) the wall and the suspended ceiling
- The mounting and horizontal alignment of the eVALVE concealed rough parts
- The mounting of the waterproof packing (eVALVE concealed rough parts, SMART TOOLS concealed rough parts)
- 900 mm / 2 ft 11-3/8" minimum distance between the circulation pipe connection (C) and the first eVALVE of the HORIZONTAL SHOWER^{ATT}

Required nominal diameter (DN) for pipes and fittings:

- DN 20 – hot and cold water pipe (HW + CW)
- DN 20 – ring main (loop)

In the main pipe:

- Filter
- Pressure reducing valve
- Water softener, if necessary
- Speed-controlled pressure booster, if necessary

Component mounting and accessibility for inspection:

- 2 x Stop valve (DN 20)
- 2 x Dirt trap (DN 20)
- Report on testing the concealed rough parts for leaks in accordance with EN 806-4 / DIN 1988-200
- Report on flushing the pipes after rough-in, in accordance with EN 806-4 / DIN 1988-200

Special features / comments

.....

.....

.....

.....

.....

.....
Order number (SO)

.....
City

.....
Date

.....
Service partner / Dornbracht

.....
Person responsible for planning

.....
Fitter

.....
Electrician

Electrical installation

Planning for the HORIZONTAL SHOWER^{ATT} can be checked for completeness more easily with this checklist.

Checks to be made:

- Maximum distances: fuse box, concealed rough parts for eVALVE, SMART TOOLS
- Electrical installation must be carried out by a professional specialist, in accordance with DIN VDE 0100. Please conform to national statutory regulations, where different.

Dimensions, positions and accessibility for inspection, mounting if necessary:

- Fuse box with 2 x DIN rail mountings TS 35 and an equipotential bonding strip
- Minimum distances: concealed rough parts for eVALVE, SMART TOOLS control elements
- All cables installed without damage
- VBUS cables between 6 x WATER BAR, hand shower set, if applicable and SMART TOOLS control elements
- Daisy chain in accordance with the planning information
- Excess cable lengths not rolled up. Cables shortened.
- Test all cables.

Arriving at the fuse box:

- 6 / 7 x equipotential bonding 4 mm² / AWG 11 for 6 x WATER BAR and hand shower set, if necessary.

In the fuse box:

- Safety cut-out (6 A)
- Ground fault circuit interrupter (30 mA, 2-pin, type A)
- 1 x Circuit-breaker switch (16 A)
- Network connection in accordance with TIA 568A, if necessary

Special features / comments

.....
.....
.....
.....
.....

.....
Order number (SO)

.....
City

.....
Date

.....
Service partner / Dornbracht

.....
Person responsible for planning

.....
Fitter

.....
Electrician

Exposed trim parts / commissioning

..... Order number (SO) Serial number Date of initial commissioning
..... Project / end customer Address	
..... Phone E-mail	
..... Additional contact Phone E-mail
..... Person responsible for planning Address	
..... Phone E-mail	
..... Fitter Address	
..... Phone E-mail	
..... Electrician Address	
..... Phone E-mail	
..... Service partner / Dornbracht Address	
..... Phone E-mail	

Exposed trim parts / commissioning

Planning for the HORIZONTAL SHOWER^{ATT} can be checked for completeness more easily with this checklist.

Checks to be made:

- (Hot and cold water) pipe flushing at the first WATER BAR
- Flush each concealed body separately before fitting the eVALVES.
- Report on flushing the pipes after rough-in, in accordance with EN 806-4 / DIN 1988-200, if necessary
- Completeness of the scope of supply of the concealed rough parts - Once the packaging is open, install the components immediately.-
- HORIZONTAL SHOWER^{ATT} fully and securely mounted (6 x WATER BAR, hand shower set, SMART TOOLS control elements, electrical components)
- Accessibility for inspection (electrics and components for the hot and cold water pipe)
- Daisy chain in accordance with the planning information
- Terminator at the end of the VBUS cables
- Components provided by customer fully and securely mounted
- Nameplate in the fuse box attached where it can be seen (e.g. door)
- Voltage in the fuse box (100 – 240 V AC, 12 V DC)
- Motherboard cable wires connected correctly.

Commissioning:

- Open the cutoff for the cold and hot water supply.
- Carry out diagnosis with eASSIST 2.X.
- Make settings with eASSIST 2.X (if asked by customer)
- Check all the functions of the HORIZONTAL SHOWER^{ATT} individually in accordance with the operating manual.
- Instruct the operator / owner how to operate the HORIZONTAL SHOWER^{ATT}.
- Hand over the Quick Info and operating manual, if applicable.
- Confirm that the HORIZONTAL SHOWER^{ATT} is working perfectly:

.....
Signature (operator / owner of the HORIZONTAL SHOWER^{ATT})

Special features / comments

.....

.....
Order number (SO)

.....
City

.....
Date

.....
Service partner / Dornbracht

.....
Person responsible for planning

.....
Fitter

.....
Electrician

Aloys F. Dornbracht GmbH & Co. KG Armaturenfabrik
Köbbingser Mühle 6, D-58640 Iserlohn
Tel. +49(0)2371 433-0, Fax +49(0)2371 433-232
mail@dornbracht.de, dornbracht.com

Dornbracht Group

Premium Solutions for Interior Architecture