

# Catalan® Medicine Cabinet K-2938-PG

### **Features**

- Four adjustable tempered-glass shelves.
- Full-overlay mirrored door.
- Mirrors on back of door and interior back of cabinet.
- Two-way adjustable hinges with 170-degree opening capability for full cabinet access.
- Can be installed with left- or right-hand swing.
- Includes mounting hardware for surface or recessed installation.
- Multiple cabinets can be joined horizontally with ganging kit (sold separately).
- Requires K-2878 side mirror kit (sold separately) for surface mount installation.

### Material

- Anodized aluminum construction with a durable rust- and chip-resistant finish.
- Anodized aluminum.

# **Required Products/Accessories**

K-2878 Mirrored side kit for Catalan® medicine cabinets

# **Recommended Products/Accessories**

K-23723 Faucet cleaner

# **Optional Products/Accessories**

K-2879 Ganging Hardware



# Codes/Standards

None Applicable

# **KOHLER® One-Year Limited Warranty**

See website for detailed warranty information.

### **Available Colors/Finishes**

Color tiles intended for reference only.


Color Code Description


SAA Satin Anodized Aluminum











<sup>\*</sup> Recess-Mount Cutout

# **Technical Information**

All product dimensions are nominal.

# **Recess-Mount Cutout:**

Width: 14-1/2" (368 mm)
Height: 35-3/8" (899 mm)
Depth: 4" (102 mm)

### **Notes**

Install this product according to the installation guide.

When determining the height of the medicine cabinet, ensure the mirrored door will clear all obstacles (such as a faucet). A minimum distance of 3" (76 mm) is required.

To find the combined roughing-in width for joined cabinets, add the roughing-in width for each cabinet and add 1" (25 mm) for each ganging kit. Secure the screws (provided) to a stud to avoid possible property and product damage. If this is not possible, anchors (not provided) must be

Roughing-in opening for recess-mount installations: 14-1/2" (368 mm) x 35-3/8" (899 mm) x 4" (102 mm).

inserted before installing the screws.

