
### **INSTALLATION GUIDELINES**

STYLE No. BLS110, BLS12A, BLS12B, BLS12C, BLS12D, BLS12E

Bond Low Profile Lavatory Faucet with Lever Handles

STYLE No. BLS130, BLS14A, BLS14B, BLS14D,

Bond Low Profile Lavatory Faucet with Knob Handles



#### STYLE No. BI S110

Bond Solo Series Lavatory with Lever Handles


- STYLE No. BLS100 Bond Low Profile Lavatory Faucet (Less Handles)
- STYLE No. BLH010 Bond Solo Series Lever Handle



### STYLE No. BL S12A

Bond Tandem Series Lavatory Faucet with Guilloche Lines Lever Handles

- STYLE No. BLS100 Bond Low Profile Lavatory Faucet (Less Handles)
- STYLE No. BLH02A Bond Tandem Series Guilloche Lines Lever Handle



#### STYLE No. BLS12B

Bond Tandem Series Lavatory Faucet with Two-Tone Lever Handles

- STYLE No. BL S100 Bond Low Profile Lavatory Faucet (Less Handles)
- STYLE No. BLH02B Bond Tandem Series Two-Tone Lever Handle



### STYLE No. BLS12C

Bond Union Series Lavatory Faucet with Guilloche Link Lever Handles

- STYLE No. BLS100 Bond Low Profile Lavatory Faucet (Less Handles)
- STYLE No. BLH02C Bond Union Series Guilloche Link Lever Handle



### STYLE No. BLS12D


Bond Union Series Lavatory Faucet with Enamel Guilloche Lines Lever Handles

- STYLE No. BLS100 Bond Low Profile Lavatory Faucet (Less Handles)
- STYLE No. BLH02D Bond Union Series Enamel Guilloche Lines Lever Handle



Bond Union Series Lavatory Faucet Guilloche Pinstripe Lever Handles


- STYLE No. BL S100 Bond Low Profile Lavatory Faucet (Less Handles)
- STYLE No. BLH02E Bond Union Series Guilloche Pinstripe Lever Handle



#### STYLE No. BL S130

Bond Solo Series Lavatory Faucet with Knob Handles


- STYLE No. BLS100 Bond Low Profile Lavatory Faucet (Less Handles)
- STYLE No. BKH030 Bond Solo Series Knob Handle



#### STYLE No. BL S14A

Bond Tandem Series Lavatory Faucet with Guilloche Lines **Knob Handles** 


- STYLE No. BLS100 Bond Low Profile Lavatory Faucet (Less Handles)
- STYLE No. BKH04A Bond Tandem Series Guilloche Lines Knob Handle



#### STYLE No. BLS14B

Bond Tandem Series Lavatory Faucet with Two-Tone Guilloche Lines Knob Handles


- STYLE No. BLS100 Bond Low Profile Lavatory Faucet (Less Handles)
- STYLE No. BKH04B Bond Tandem Series Two-Tone Guilloche Knob Handle



### STYLE No. BLS14D

Bond Union Series Lavatory Faucet with Enamel Guilloche Lines Knob Handles

- STYLE No. BLS100 Bond Low Profile Lavatory Faucet (Less Handles)
- STYLE No. BKH04A Bond Tandem Series Guilloche Lines Knob Handle
- STYLE No. BKHOOD Bond Union Series Fnamel Index



### STYLE No. BLS15C

Bond Union Series Lavatory Faucet with Guilloche Link Knob Handles

- STYLE No. BLS100 Bond Low Profile Lavatory Faucet (Less Handles)
- STYLE No. BKH05C Bond Union Series Guilloche Link Knob Handle

### **INSTALLATION GUIDELINES**

**STYLE No.** BLS110, BLS12A, BLS12B, BLS12C, BLS12D, BLS12E

Bond Low Profile Lavatory Faucet with Lever Handles

STYLE No. BLS130, BLS14A, BLS14B, BLS14D, BLS15C

Bond Low Profile Lavatory Faucet with Knob Handles

### **IMPORTANT:**

- > To ensure this product is installed properly, you must read and follow these guidelines.
- > The owner/user of this product must keep this information for future reference.
- > This product must be installed by a professional licensed contractor.
- > Be sure your installation conforms to federal, state, and local codes. In the State of Massachusetts, all installations must comply with the rules and regulations set forth within 248 CMR.
- > Inspect this product to ensure you have all the parts required for proper installation.
- > Product is sold partially assembled but shown fully disassembled for illustrative and service purposes only.
- > CAUTION: Use only a strap wrench or protected/smooth-jaw wrench on ANY finished surface.
- > CAUTION: This product is supplied with a DRAIN that is NOT compatible with SINKS that have a 1-1/2" [38mm] drain hole. A 1-3/4" drain hole is REQUIRED.
- > The use of certain plumber's putty may stain stone or tile surfaces.
- > If further assistance is required, please contact Product Support at 1-800-927-2120 Monday through Friday, 8am 6pm EST.
- > Refer to the separate Service Parts Documents for available replacement parts.

### **TECHNICAL DETAILS:**

DETAIL	SPECIFICATION
DECK THICKNESS MAXIMUM	1-11/16" [43mm]
DECK THICKNESS MINIMUM	1/4" [6mm]
DRAIN DEPTH MAXIMUM	2-5/8" [67mm]
DRAIN DEPTH MINIMUM	3/8" [10mm]
DRAIN HOLE DIAMETER	Ø1-3/4" [44mm]
DRAIN STYLE	PUSH-TOUCH
FITTINGS HOLE DIAMETER	Ø1-3/8" [35mm]
HANDLE SPREAD MAXIMUM	12" [305mm]
HAND SPREAD MINIMUM	8" [203mm]
HANDLE TURN ANGLE	QUARTER TURN
INLET CONNECTION	1/2" MALE WITH SUPPLY NUT
SPOUT REACH	5-5/8" [143mm]
WATER PRESSURE MAXIMUM	85psi [6.0 bar]
WATER PRESSURE MINIMUM	20psi [1.5 bar]
WATER PRESSURE RECOMMENDED	45psi [3.0 bar]


### INSTALLATION GUIDELINES

STYLE No. BLS110, BLS12A, BLS12B, BLS12C, BLS12D, BLS12E


Bond Low Profile Lavatory Faucet with Lever Handles


STYLE No. BLS130, BLS14A, BLS14B, BLS14D,

Bond Low Profile Lavatory Faucet with Knob Handles




WASHERS from the SPOUT SHANK.






4. Unthread and remove the TRIM CONNECTOR and FOAM WASHER from the SIDEBODY then fully thread the NUT down the SIDEBODY.


NOTE: Do NOT remove the LOWER DECK WASHERS and SPACER.




2. Insert the SHANK through the hole on the mounting surface, making sure the FOAM GASKET is beneath the ESCUTCHEON, then re-install the LOWER DECK WASHERS and securely tighten the NUT.



Thread and securely tighten the TEE onto the SHANK making sure to use the FIBER WASHER provided.



5. Using the FOAM WASHER provided, thread the TRIM CONNECTOR back onto the SIDEBODY until it stops then let it rest on the mounting surface.



6. Ensure the SIDEBODY is positioned so the SUPPLY HOSE can be easily connected to the TEE then thread and securely tighten the NUT against the underside of the mounting surface.

NOTE: Repeat steps 4 - 6 to insall the 2ND SIDEBODY.

PAGE 3 OF 6 | UPDATED ON 3.05.2020

### **INSTALLATION GUIDELINES**


STYLE No. BLS110, BLS12A, BLS12B, BLS12C, BLS12D, BLS12E

Bond Low Profile Lavatory Faucet with Lever Handles

STYLE No. BLS130, BLS14A, BLS14B, BLS14D,

Bond Low Profile Lavatory Faucet with Knob Handles

**STEPS 7 - 8 FOR KNOB HANDLE ONLY** 




PROCEED TO STEP 11

NOTE: To remove the INDICE push down on and rotate it 45° then release.

re-attach the INDICE.

NOTE: Repeat steps 7 - 8 to install 2ND HANDLE.

**STEPS 9 - 10 FOR** LEVER HANDLE **ONLY** 



PROCEED TO **STEP 11** 


### **INSTALLATION GUIDELINES**

**STYLE No.** BLS110, BLS12A, BLS12B, BLS12C, BLS12D, BLS12E


Bond Low Profile Lavatory Faucet with Lever Handles

STYLE No. BLS130, BLS14A, BLS14B, BLS14D, BLS15C


Bond Low Profile Lavatory Faucet with Knob Handles



 Connect the SIDEBODIES to the TEE using the SUPPLY HOSES provided. Securely tighten the HOSES and ensure they are not pinched/kinked.




12. Unthread and remove the NUT, TAILPIECE, and RUBBER WASHER from the LOWER DRAIN BODY.




13. Unthread and remove the DRAIN STOPPER and LOWER DRAIN BODY from the DRAIN FLANGE.


NOTE: Do NOT remove or discard the LOWER DRAIN GASKET.



14. Set the DRAIN FLANGE into the LAVATORY (sold separately) using putty or a clear adhesive silicone.



15. Using the LOWER DRAIN GASKET and SCREW provided, re-attach the LOWER DRAIN BODY to the FLANGE. Ensure the GASKET makes a full seal on the underside of the LAVATORY then securely tighten the SCREW.



Re-install the DRAIN STOPPER and TAILPIECE using the WASHER and NUT provided.


## **INSTALLATION GUIDELINES**

**STYLE No.** BLS110, BLS12A, BLS12B, BLS12C, BLS12D, BLS12E


Bond Low Profile Lavatory Faucet with Lever Handles

STYLE No. BLS130, BLS14A, BLS14B, BLS14D, BLS15C


Bond Low Profile Lavatory Faucet with Knob Handles



17. Make final P-TRAP (sold separately) and SUPPLY VALVE (sold separately) connections.



18. Remove the AERATOR, turn on the water supply and open the HANDLES to flush out the supply lines, and inspect all connections for leaks then close the DRAIN to ensure it functions properly.



19. Close the HANDLES, open the DRAIN to drain the water, and re-install the AERATOR.